

Adhere 3" of the flashing over the SlopeShield Plus SA on the deck.  
Adhere the remaining 16" onto the end grain. Allow the remaining flashing roll, with release film on the back, to hang down.

# Mass Timber Moisture Protection

## PRODUCT DESCRIPTION

SlopeShield Plus Self-Adhered is a highly vapor permeable roofing underlayment Air Barrier (AB) material



WallShield IT Integrated Tape is a primary, water resimpermeable, vapor permeable, air, mechanically attached sheet membrane

## DISCLAIMER

Detail sketch is generic, representing suggested best practices for VaproShield materials, and does not represent a specific job site condition and therefore may not be applicable to certain projects. Detail sketch is designed for use as a reference and must be approved by the designer/ consultant of record for each project prior to installation by the subcontractor. Changes and approvals of VaproShield details are the sole responsibility of the designer/consultant of record. VaproShield is **not** the designer of record for building enclosure details and takes no responsibility for the accuracy or interpretation of actual project site conditions.

Always check [www.VaproShield.com](http://www.VaproShield.com) for the latest details and installation instructions

VaproShield LLC  
915 26th Ave. N.W. Suite C5  
Gig Harbor, WA 98335  
Toll Free: 1.866.731.7663  
[www.VaproShield.com](http://www.VaproShield.com)  
© VaproShield 3/15/2025



In high wind areas install nailing strip or term bar for added wind protection

Using a roll of 19" SlopeFlashing, slit the release film approx. 6" from the top

Apply VaproTape over the flashing seam.  
NOTE: Taping over lap edges in field may be omitted where slope is greater than 2:12.

Protect end grains from damage and facilitate rapid water removal